

Acrylic surface repair

MINOR acrylic surface repair

Oceania Baths suggests the following instructions for the repair of minor scratches or blemishes on acrylic surfaces. This basic procedure may be used as long as the scratch or blemish has not penetrated the acrylic surface to reach the fibreglass laminated coating underneath.

- Start by sanding the damaged area with a #600 grit sandpaper, until the surface is smooth
- Follow up by sanding with a #1000 grit to further refine the surface
- Lightly wet a #1500 grit sandpaper and continue sanding to achieve a smooth surface
- Apply an automobile polishing cream on the repaired area, ensuring full coverage
- Finally, use a polishing machine to polish the repaired area until it matches the surrounding surface.

MAJOR acrylic surface repair

In the event of a deep scratch or blemish, where the fibreglass laminated sub-surface has been penetrated, Oceania Baths should be contacted in order to recommend an acrylic repair professional.

Never try to repair a deep scuff or blemish without proper instructions from a professional.

Please contact our Technical Support:

Email: support@oceaniabaths.com

Tel: 1-877-332-4224