









Right





Left





1 1X 	2 1X 	3 1X 	4 1X 	5 1X 	6 1X 	7 8X 	8 4X ST 4X40
9 1X ST 4X25 	10 2X 	11 1X 	12 2X 	13 2X 	14 1X 	15 2X 	16 2X
17 2X 	18 4X ST 4X40 	19 1X 	20 1X 	21 1X 	22 1X 	23 1X 	24 1X
25 1X 	26 1X 	27 1X 	28 1X 	29 2X 	30 1X 	31 1X 	32 2X M5X25
33 1X 	34 1X 	35 1X 	36 1X 	37 1X 	38 3X 	39 3X ST 4X40 	40 4X
41 4X 	42 1X 						










1

model	A (mm)		A (")	
	min	max	min	max
48"	1168	1188	46	46 3/4
60"	1473	1493	58	58 3/4

min= 30 1/4"(769mm)
max= 30 5/8"(779mm)







3






Wedge spacer is to put under glass door for level only if necessary.





Les cales sous le verre servent à la mise à niveau et sont facultatifs.



4





5



6



7



8

