



AEROMASSAGE AND SUPER AEROMASSAGE SYSTEM MAINTENANCE

For regular cleaning:

It is recommended to perform this maintenance quarterly.

1. Fill the bathtub with hot water up to 2" (5 cm) above the highest jet.
2. In a separate container, dissolve 2 to 3 teaspoons of baking soda or powdered dishwasher detergent, along with up to 4 oz (113 ml) of household bleach. Add the solution to the bathtub water.
(CAUTION: Excessive amounts of bleach may damage the bathtub surface.)
3. Run the system for 30 seconds, then stop for 1 minute. Repeat this cycle 5 to 10 times.
4. Drain the bathtub and refill it with cold water above the jets. Run the system for 30 seconds, then stop.
5. Drain the bathtub completely and wipe it dry.

For deep cleaning:

It is recommended to perform this maintenance once a year or after a long period of non-use of the system.

1. Fill the bathtub with hot water up to 2" (5 cm) above the highest jet.
2. In a separate container, dissolve 2 to 3 teaspoons of baking soda or powdered dishwasher detergent, along with up to 4 oz (113 ml) of household bleach. Add the solution to the bathtub water.
(CAUTION: Excessive amounts of bleach may damage the bathtub surface.)
3. Run the system for 1 minute, then stop and let it sit for 15 to 20 minutes. Repeat this cycle 10 times.
4. Drain the bathtub and refill it with cold water above the jets. Run the system for 30 seconds, then stop.
5. Drain the bathtub completely and wipe it dry.

To contact our **technical service:**

Email: support@oceaniabaths.com