

Installation Procedure for Rupert Freestanding Bathtubs & Banook



Serial Number: _____

Model Name: _____

Date of Manufacture: _____

Thank you for choosing an Oceania product for your project!

- For **WARRANTY** information, refer to our website: <http://www.oceania-attitude.com>
- The structure supporting your bathtub must withstand a **MINIMUM LOAD** of 1200 lbs (545 kg)
- Please **REFER** to the building code in effect in your area to ensure installation complies with applicable standards
- **PROTECT** your product during installation
- **WAIT** until the bathtub has been received before making any cuts (floor, podium, faucet, conduits); measurements must be taken directly from the product
- The services of a **QUALIFIED PLUMBER** are required for the installation of the plumbing and bathtub

IMPORTANT:

READ AND CAREFULLY FOLLOW ALL INSTRUCTIONS BEFORE INSTALLING THE PRODUCT.

1. **DANGER:** To reduce the risk of injury or drowning, do not allow children to use this product unless constantly supervised by an adult.
2. **CAUTION:** To avoid injury, exercise care when entering or exiting the bathtub.
3. **CAUTION:** Risk of accidental injury or drowning: Do not consume alcohol, drugs, or medication before or during the use of the bathtub.
4. **CAUTION:** Risk of electric shock: Keep electrical devices such as hair dryers, lamps, phones, radios, or televisions at least 5 feet (1.5 meters) away from the bathtub.
5. **CAUTION:** Risk of hyperthermia and possible drowning: Water temperatures above 100°F (38°C) can be hazardous to your health. Check and adjust the water temperature before using the bathtub.
6. **CAUTION:** Misuse of essential oils in high concentrations can irritate the skin and damage the bathtub's surface. Some brands of Wintergreen essential oils are known to damage acrylic surfaces.

1. Unwrap and inspect the product.



2. The installation of the Rupert or Banook bathtub must be made on finished walls.

Place the bathtub in its final position along the finished walls. Adjust the legs so that the bathtub rests on its 4 legs, the skirt not touching the ground.


Note: For best results, install the bathtub on a perfectly leveled floor. If the floor is not leveled, it is the installer's responsibility to adjust using the leveling legs, to make sure the tub will drain correctly.



Space between the skirt and the floor.

Regular Installation without FBQD


3. If necessary, prepare the plumbing on the floor to obtain the correct height for the drain.





If using a FBQD
Adaptator for freestanding
tubs, please refer to the
following installation video



4. Make a test without applying glue, to ensure the correct height of the plumbing.



5. Apply silicone under the 4 legs of the bath, and the appropriate glue on the connecting joint (PVC). Install the bath in its final position.



6. Apply a silicon suitable for a humid environment (anti-mould) at the junction of the walls and the bath to seal it.

Note: It is possible that the contour of the bath does not perfectly match the shape of the walls. If so, the silicone will also serve as a visual blemish concealer. Let the silicon cure for 24h before using.

